



Flats are .035 deep and can be placed on both sides of the rod which would make the rods more universal. However the flats only need to be on the bottom.

Material is Drill Rod or hardened steel shafting.
Make 2 each.

Tap_Drill_Stand	
Horiz_Support_Rod	
03/08/2025	JR